




# Dell Optiplex 745 Small Form Factor Optical Drive Replacement

The optical drive reads CDs/DVDs that are inserted. Removing the drive for replacement only takes a few simple steps!

Written By: Tyler Whalen



## INTRODUCTION

This guide will show the reader how to replace the optical (CD/DVD) drive.

## Step 1 — Opening the case



- Pull the tab and the lid will pop up.



## Step 2



- Grab the lid and pull it up and off.



### Step 3 — Disconnecting the cables



- Pull out both sets of cables from the side of the optical drive.
- ⓘ Both cables are plugged into the drive right next to each other.

### Step 4 — Removing the optical drive



- Pull the tab up holding the optical drive in place.
- Slide the optical drive out.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-30 05:29:19 AM.